

## **F1**

### Introduction

Earlier chapters have addressed the theory of the Loran-C system. This chapter narrows the focus to the shipboard component of the system Loran-C receivers. Specifically, this chapter provides an overview of the key features and characteristics of Loran-C receivers relevant to the navigator. Readers wishing to learn about the operating instructions for a specific make and model of loran receiver are advised to consult the appropriate owners manual for details. As of this writing, there are at least 25 brand names of marine Loran-C units, (and several manufacturers of aircraft lorans)<sup>1</sup> and most manufacturers produce several models so the user has a wide array of choices. Available Loran-C receivers differ substantially in design, type of displays, and operating instructions, making it impractical to cover this information in requisite depth in a chapter of reasonable length. Moreover, any such discussion would rapidly become obsolete because new models are continually being introduced.

This chapter serves as a supplement to the owners manual, providing perspective, rationale, and theory to explain the features of modern Loran-C receivers. Prospective purchasers of a loran receiver may also find this chapter useful to identify the potentially desirable features of loran sets. Readers should be aware, however, that neither the Coast Guard nor any other agency of the U.S. government has the responsibility of performance evaluation or publication of comparative performance statistics of recreational vessel loran receivers although marine lorans used on certain types of vessels and aircraft lorans must meet technical performance criteria. (There are private sector publications that do present technical data and frank evaluations of Loran-C receivers.) It is also worth reminding the reader that receiver photographs included in this handbook are for illustrative purposes only and should not be construed as endorsements of any particular make or model.

As with this handbook generally, the focus of this chapter is on marine users. Where appropriate, supplemental material relevant to other users is included.

### Read Your Owners Manual

Although all Loran-C receivers operate on the same general principles, there are important differences among these receivers in features, methods of operation, and even in the definitions of terms used in the operating instructions. For example, one manufacturer uses the term velocity along route (VAR) to describe the component of the aircraft's or ships speed over the ground in the direction of the course (more below), while other manufacturers use terms such as velocity made good (VMG) or speed of advance (SOA) to describe the same term. As a second example, one manufacturer calculates the time-to-go (TTG) to the next waypoint as the distance to the waypoint (distance-to-go, DTG) divided by the speed over the ground, another as the DTG divided by the component of the ground speed in the direction of the waypoint.

The control buttons of different receivers have different names (or alphanumeric designators), and operating procedures likewise differ.

The only way to master a particular make and model of Loran-C receiver is to read the accompanying manual, and call the manufacturer (or dealer) if you have any questions.<sup>2</sup> The old saw: when all else fails, read the directions, is simply not good advice when it comes to today's sophisticated marine electronics or avionics. There is no substitute for careful study of the owners manual.

Owners manuals differ significantly in the amount of detail presented, and in their clarity and accuracy. The prospective purchaser is well advised to read this document and include the quality of the manual among the attributes to be considered in the purchase decision.

The old saw:

when all else fails, read the directions, is simply not good advice when it comes to today's sophisticated marine electronics. There is no substitute for careful study of the owner's manual.

#### Generations of Loran-C Receivers

Although the earliest Loran-C receivers were a substantial improvement over Loran-A receivers, these early (so-called first generation) Loran-C receivers were extremely primitive by today's standards. The first Loran-C models were difficult to operate (similar to the Loran-A sets), and provided only TD information. Later (so-called second generation) models offered little more than a display of measured TDs from two secondaries in a Triad. Users would need to specify the GRI and secondaries to be tracked, and take the measured TDs, convert these to latitude and longitude if desired, and otherwise do the time-honored navigators' days work of plotting, determining course to steer, estimated time enroute (ETE), estimated time of arrival (ETA), and the many other tasks common to the practice of navigation.

The advent of microchips and miniaturization of computers over the years since the Loran-C system has been in place has created a revolution in the design and features of the modern receiver. Loran-C receivers now select chains and secondaries, automatically convert TDs to latitude/longitude, warn of any lack of system integrity, do many of the typical calculations made by navigators, and talk to other on-board electronic systems, such as radar, electronic charts, autopilots, and other marine electronics. If the early receivers could be called radios in some sense, the later receivers should really be termed navigation computers. Additionally, the price of full-feature lorans has decreased substantially over the years, as manufacturers amortized research and development expenditures, captured economies of scale, and responded to competitive pressures. Receivers have, therefore, become much more affordable for owners of recreational vessels and aircraft.

Considering the sophistication of most modern receivers, these are remarkably user friendly (i.e., easy to operate). Nonetheless, it requires time and some diligence to master the use of a given receiver not unlike that required to use a computer. Although some lorans are much easier to operate than others, all require a modicum of user sophistication.

#### Features

This section describes the relevant features of various Loran-C receivers now available commercially. Not all receivers include all of the features discussed below, but all of these features can be found among commercial loran sets. Some manufacturers use company-unique or trade names different from those in this handbook to describe these features.

Receivers differ widely in the number and type of features offered. The features discussed here provide a useful sample for the prospective purchaser.

#### Basic Function: Reception and Display of Position Information

In broad terms, the functions of the Loran-C receiver are to acquire and lock on the appropriate transmissions and, at a minimum, to display the TDs associated with the selected master-secondary station pairs. Additionally, all receivers now being marketed have the capability to convert from TDs to latitude and longitude, termed a coordinate conversion capability. All modern receivers also have a navigation mode that enables the user to monitor the progress of a flight or voyage, and make necessary corrections to stay on course.

Receiver circuit designs are generally proprietary and, in any event, beyond the scope of this handbook. Nonetheless, receivers do employ different hardware

and software,<sup>3</sup> and differ substantially in their ability to acquire and process signals. These differences can be important to the mariner particularly a mariner who frequents fringe areas near the limits of the coverage area or areas where interference is high. With some older receivers, it is necessary to select the chain and the station pairs as part of the setup process. Newer receivers incorporate automatic transmitter selection (ATS) or automatic initialization, as it is sometimes called. If the receiver has this capability, all the user need do to initialize the set is to enter the user's latitude/longitude, and the set automatically selects the best 4 GRI and station pairs. This feature is convenient, but (as noted in Chapter III) it is sometimes necessary to override this automatic selection.

Once the GRI and the secondaries are selected, the receiver goes through a sequence of steps to search for, acquire, settle, and lock-on to the transmissions from the desired secondaries. Table IV 1 identifies the generic steps in signal acquisition and lock. The time for receivers to complete these steps varies with the receiver and the SNR of the master and the secondaries. Typically, this time varies from less than a minute for very strong signals to 15 minutes or more for signals with low SNRs. Most receivers display an alphanumeric code to identify the stage of the setup procedure. As noted in earlier chapters, the requisite SNR for reception differs with the receiver. The SNR required for acquisition is generally greater than that for tracking. This is why it sometimes occurs in an out-and-back trip that the loran receiver can continue to track a previously acquired signal in circumstances where the same receiver could not acquire the signal.

Some receivers can acquire and track only a master and two secondaries, while others can acquire and track all usable secondaries in a chain. Although two loran LOPs are sufficient to determine a fix, reception of additional secondaries is desirable. As noted, the availability of an additional secondary can be used to resolve ambiguous positions when operating near areas of baseline extension. Moreover, statistical techniques can be used (Kalman filtering) to derive more precise position information if three or more LOPs can be measured. The receiver's computer automatically determines the position which minimizes the weighted mean square error of all the LOPs. At least one receiver manufacturer has designed a Loran-C unit with the capability to use signals from two chains simultaneously a so-called dual-chain receiver. Statistically optimal positions can be derived from LOPs from many station pairs from the two chains. An advantage claimed for the dual chain receiver is that it can provide accurate positions at greater distances than single-chain counterparts.

It is important to note, however, that simply because a Loran-C receiver tracks all secondaries does not mean that it is capable of using information from more than two master secondary pairs in the manner noted above. Prospective purchasers are cautioned to read the user's manual carefully on this point.

Users should consult their owners manuals to determine exactly which chains can be received by the set some are capable of tracking all extant GRIs (including the USSR system), while others are more limited. The introduction of new chains (e.g., the recent SOCUS and NOCUS chains) may require software revisions for adequate reception on older models.

#### Displays

Nearly all modern marine loran receivers use a liquid crystal display (LCD), which is energy efficient and easy to read in daylight as well as darkness.<sup>5</sup> Dimmer switches are handy to control nighttime cockpit or nav-station light levels. These displays indicate position information (TDs or latitude/longitude) as well as many other ancillary quantities (stations in use, signal characteristics, navigational information, etc.). The size of the

display screen varies among models. Some models feature paged displays in which different information is displayed on different pages of the display. By pressing a mode or other key, the user can page through the available information. Some lorans can interface with voice synthesizers, so that the user does not have to look at a display to acquire necessary information. A mechanical voice continually broadcasts data from the receiver. Some users find lorans equipped with voice synthesizers to be very convenient; to others this feature is an irritating distraction.

Prospective receiver purchasers are well advised to pay particular attention to the type of display screen of the set. This may seem an odd point to emphasize, but it is absolutely true that the most sophisticated Loran-C receiver in the world is of little use, unless the navigator can quickly read and interpret the available information. As with many other features of the loran receiver, the design of the display reflects numerous compromises and tradeoffs. A large screen, for example, is more costly, consumes more power, and may be incompatible with the overall size of the receiver. The available information from a Loran-C receiver (see below) includes status indicators and warning information, identification of the GRI and secondaries in use, SNRs of the master and secondaries chosen, alarm settings, position information (in latitude/longitude or TDs), and navigational information (e.g., waypoint descriptors, bearing and distance to waypoint, ETE/ETA information, cross-track errors, speeds, and courses, to cite just a few elements). In total, a modern Loran-C receiver may have the capability of displaying hundreds of pieces of potentially relevant data. Practical constraints limit the overall size of display screens, and size of lettering/numbering, so that it would be impossible (let alone confusing) to present all this information on one display. Segmenting the display into pages, each with defined and logically grouped contents is a viable design alternative. However, paged displays do not solve all problems. For example, a user cannot simultaneously examine the contents of more than one page so that not all information is rapidly accessible.

Large clear numerals or letters (without distracting and hard-to-read letters made from numerals) are easiest to read. It is also helpful if the screen can display several items at once (perhaps in different sizes) so that the user does not continually have to switch pages to find related information. Some information is more easily and rapidly understood in analog (e.g., pointers, arrows, etc.) rather than digital form. Arrows, symbols, or mini-charts, if well designed and logically grouped, can also enhance the interpretability of a display. So-called menu screens (i.e., those with self-prompting inputs) can ease the task of entering data.

Display screens differ in the viewing angle, through which the numbers can be clearly read. Some displays are quite difficult to read when not standing directly in front of the set.

Finally, the display should be evaluated in terms of where the loran receiver will be mounted in the vessel. Mounting directly in front of the helm station (e.g., on a power vessel) may not require a display as large as if the set were mounted at some distance from the navigator's eye, as might be required on a sailboat. Aircraft lorans are generally rack mounted on the instrument panel.

Receiver displays are a very important feature. Ideally, the display should be large and easy-to-read, keeping key information readily in view.

#### Keypad

The keypads used on loran receivers differ. Some use membrane or flat keypads, others use raised keys. In general, raised keys (as on a computer keyboard) have a better feel, and are easier to use. Membrane keypads are easier to make waterproof or water-resistant, however.

Some receivers emit a beep when a key is depressed and the information is entered. This feature compensates, to some degree, for the lack of tactile sensation when using a membrane keyboard.

The size of the keys likewise differs among receivers. Closely spaced keys invite entry errors, particularly when on the bridge of a pitching or rolling vessel, or in the cockpit of an aircraft encountering turbulence.

Nearly all receivers have a numeric keypad (in addition to function keys). On some models, however, it is necessary to push  
+ or

buttons to increase or decrease an entryan inconvenience when entering waypoint coordinates.

Some marine lorans have calculatorstyle numeric keyboardsi.e., with the keys 7-8-9 on the top row. Other marine lorans have telephone style numeric keyboardsi.e., with the keys 1-2-3 on the top row. There is no best choice for the keyboard type,but a matter of individual preference.

#### Remote Readout

Some receivers offer the option of a remote readout or display to be used instead of, or in addition to, the principal readout. Receivers with this feature can be used to provide navigational information in two locations, such as at the bridge and at a separate navigators station. Of course, the same effect can be achieved by using two loransone at each stationbut the remote readout ensures that both stations display the same navigational information, and at a cost somewhat less than that for a second loran.

#### Coordinate Conversion

All modern marine Loran-C receivers have the capability of displaying position information as TDs or as latitude/longitude. (Aircraft lorans use latitude/longitude exclusively.) TDs are what is measured by the receiver in all cases, and these are converted to latitude/longitude by mathematical algorithms using ASF information (e.g., the tables shown in Chapter II) stored in computer memory.<sup>6</sup> Some manufacturers have gone to great lengths to ensure that ASFs are as accurate as possible.

Although the ASFs stored in the internal memory of the Loran-C receiver are highly accurate for many makes and models, this is not true uniformly. Studies conducted at the Coast Guard Research and Development Center in Groton, CT (see Frazier, 1988), indicated that the internal ASF tables in some models were very inaccurate for some locations. Indeed, for some makes and models, the internal ASF corrections resulted in greater latitude/longitude errors than if no corrections were applied at all. As of this writing, there is no industry standard for coordinate conversion,<sup>7</sup> and each manufacturer uses a slightly different variant. It is possible, therefore, for two Loran-C receivers located next to each other to register exactly the same TDs, but slightly different positions in latitude and longitude terms.

Because of this lack of standardization, and because ASFs are only approximate in any event, use of TDs is preferred for most accurate navigationalalthough accuracy differences may not be large for top-of-the-line Loran-C receivers.

(As noted above, aircraft loran receivers provide latitude/longitude information only. The width of a typical airway [ highway in the sky] is 4 nautical miles either side of a centerline, so

precise position information is less important in the enroute mode. When making instrument approaches to airports, standard ASFs appropriate to each airport are entered into the loran from the published instrument approach procedure.)

When prestored ASFs are being applied, there is generally some indication on the display (e.g., the code sequence ASF ) to indicate that this is the case. (Most lorans also enable the user to input a predefined ASF, latitude/longitude offset, or bias as an alternative to the stored values.)

Experienced navigators needing optimal Loran-C accuracy are well advised to use TDs rather than latitude and longitude. Published waypoints are often given in TDs as measured.

#### Notch Filters

Loran-C signal reception can be impaired by interference from other signals, broadcast on slightly different frequencies (e.g., radio broadcast stations, military radio transmitters, and other navigation equipment). Appendix A provides a list of known sources of interference in the United States, Canada, and Mexico.. The severity of the effects of interfering signals is a function of many factors, but interfering signals can reduce the SNR of the loran signal and degrade the accuracy of the position determined.

To avoid the degradation in SNR associated with these interfering sources, loran sets are equipped with so-called notch filters that can be used to attenuate or notch out the interfering signal. Some receivers contain built-in spectrum analyzers to display levels of interfering signals, a useful feature when setting adjustable notch filters. Some receivers are equipped with preset notch filters, others with adjustable notch filters, and yet others with so-called Pac-man or seek and destroy filters. These latter filters automatically search for interfering signals near the loran band and dynamically notch out this interference. Refer to the owners manual for instructions on how to use the notch filters for a particular make and model of receiver.

It should be noted that the purpose of notch filters is to control the effects of interfering signals, not any noise or interference associated with shipboard equipment. Control of internal noise sources is addressed in more detail in Chapter VII.

#### Integration with Other Systems

Loran-C receivers can be integrated with other shipboard systems in two ways. Some Loran-C receivers are actually built into another piece of electronic gear, e.g., a depth sounder, fish finder, or plotter. Some receivers are integrated with GPS, offering additional flexibility and redundancy. As well, most receivers have output jacks with a standardized output (three common protocols are the National Marine Electronics Association, NMEA 0180, 0182, and 0183 formats) that enables interconnection with plotters, video charts, autopilots, and radars. Some models can also be interconnected with a gyrocompass or fluxgate compass and speed log enabling the electronic determination of the set and drift of the current. This interface capability can be a considerable help to the navigator. Prospective purchasers should ensure that the correct output formats are available to tie into ancillary equipment.

#### Data Bases

Some Loran-C receivers, typically those intended for use on aircraft, but also some marine models, incorporate a self-contained data base. On an aircraft loran, for example, this data base would contain the

locations of the thousands of airports throughout the country. The user can call up attributes of the airport (e.g., the longest hard surfaced runway) with only a few keystrokes, and navigate to this airport. In the event of an in-flight emergency, the loran receiver can display the distance and bearing of the nearest airfield having the requisite runway characteristics. Likewise, marine loran receivers with data bases contain the locations of buoys and other features of navigational interest. One marine loran comes with a data base of approximately 8,000 lights and 6,000 buoys, along the coast of the continental United States, Great Lakes, Hawaii, and Alaska.

A data base can be very convenient, but it is also necessary to have some means to update the data base as the locations of the entries or other information changes. With aircraft lorans, a cartridge is shipped periodically to update the original factory supplied data.

#### Magnetic Variation

Most Loran-C receivers are equipped with a chip that provides magnetic variation data throughout the areas of the world covered by the loran chains that can be used by the receiver. On some models, this data base includes average annual changes in variation. Once the user enters the date and year, the receiver can compute the variation at any relevant location. In practice, therefore, the user can do all navigation with reference to either true or magnetic north. (Deviation is not accounted for on any production loran as of this writing.) When directions are referenced to magnetic north, the loran receiver displays a flag, such as MAG or other abbreviation to indicate that directions are referenced to magnetic, rather than true, north.

#### Power Requirements

Nearly all Loran-C receivers used by recreational vessels or aircraft operate on DC power. In most cases, these receivers are designed to use on board power. Consult the specifications for each receiver for the acceptable voltage range (e.g., 10 15 volts or 7 40 volts). However, some receivers are portable, and use self-contained batteries (e.g., 6 AA cells). (Power batteries should not be confused with those lithium batteries required to maintain the receivers waypoint memory.)<sup>8</sup>

If the voltage drops outside of the acceptable range (because the batteries are run down, or as a result of starting the engine), the loran receiver may crash, and have to begin the entire acquisition-to-lock cycle anew. This could cause a problem if, for example, the engine(s) were shut down to increase the likelihood of hearing a sound signal from a critical buoy in circumstances of restricted visibility. If, on restarting the engine(s), the loran were to crash, the navigator would lose critical navigational data at an inopportune time. Where possible, it is desirable to use a different battery to power marine electronics from that used to start the engine(s).

Power requirements for Loran-C receivers are typically quite modest. As Table IV

1 shows, Loran-C receivers do not draw much current (e.g., 0.15 to 1.75 amperes among a sample of 20 receivers), at least in comparison to many other types of marine electronics found on board a recreational vessel. Thus, to operate a Loran-C receiver for a 24-hour period would require from 3.6 to 42 ampere-hours.

Power requirements for Loran-C receivers are typically quite modest compared to other marine electronics. This enables Loran-C receivers to be operated almost continuously on sailboats, power vessels or aircraft experiencing alternator failure.

Power requirements for marine electronics are relevant not only for selecting the storage batteries and sizing the generator (alternator), but also for designing a load shedding strategy in the event of alternator failure. A heavy-duty marine battery of 100 ampere-hour rating, for example, could supply current to service the ships electronics load at the rate of 100 amperes for one hour, 50 amperes for two hours, 25 amperes for three hours, etc., without being recharged. In the event of alternator failure, all nonessential electrical equipment would be shut off to conserve the battery. Mariners are left to decide exactly what is nonessential, depending upon the circumstances of the voyage. As Table IV 2 indicates, the current drain for most lorans is sufficiently small that the loran receiver would probably not have to be shut down in the event of alternator failure. Even this small draw could be reduced by the simple expedient of shutting off the display lights and using a small flashlight for illumination if necessary.

#### Automatic Alarms and/or Status Indicators

Most Loran-C receivers have the capability to display a variety of automatic alarms and/or status and warning indicators. Table IV 3 provides a sample of these alarms and status and warning indicators for marine lorans. These alarms and the names and display codes vary from receiver to receiver, so the owners manual should be consulted for details. For example, one receiver model combines all of these alarms into one warning flag, wait, to indicate that positions displayed by the loran may be unreliable. On this model wait is displayed if there is a low SNR, cycle error, blink code, etc. Other models are capable of displaying much more detailed information. In general, it is desirable to have more detailed information, because the user can often intervene (e.g., by switching secondaries) to remediate the problem.

With one exception, the definitions of the alarms and status indicators in Table IV

3 are clear and do not need elaboration. It is appropriate, however, to say a few words more about SNR indications on Loran-C receivers. SNRs are very important to the user.

Low SNRs warn the user of possible acquisition or tracking difficulties, the need to switch secondaries, and/or that on-board electrical interference problems exist.

High SNRs are generally desirable but abnormally high SNR values in what would otherwise be fringe areas could warn of skywave contamination (see Chapter II). For these and other reasons, SNR values are important to the mariner.

Some Loran-C receivers display SNR information only in qualitative terms, e.g., by letter codes (e.g.,

A = excellent,

B = very good, etc.) or word descriptors such as very low or

very high. Other sets display a two or three digit numerical code e.g., ranging from 00 to 99, where 00 is worst and 99 is best. Pay particular attention to the text in the owners manual to interpret the SNR values provided by a particular make and model.

A measure of the signal-to-noise ratio favored by electrical engineers is the SNR in decibels, abbreviated dB. The SNR in dB is numerically equal to  $20 \log (\text{SNR})$ . Thus, for example, an SNR of 0.5 would be equal to -6.02 dB.

Equivalently, the SNR corresponding to a particular dB reading is  $\text{SNR} = 100.05^{\text{dB}/20}$ . Table IV

4 shows the relationship between the SNR (as a fraction) and the equivalent in decibels. As can be seen from inspection of this table, the SNR in dB will change by approximately six units whenever the actual SNR is either doubled or halved. Some Loran-C receivers have the capability of displaying SNR values in



dB. This display is preferable because, alone among the various methods of indicating SNR, the actual SNR value can be calculated from the dB figure.<sup>9</sup>

SNR displays are useful for setting notch filters, determining the sources and significance of shipboard electrical interference, detecting skywave contamination, and selecting secondaries for use. Quantitative displays showing the actual SNR (as a ratio or in decibels) are best.

#### Recording SNR Data in the Navigation Log

Navigators should make it a practice to record the SNR for various stations as a memo item in the navigation log for each trip. Over time, a data base can be assembled that will provide the navigator with a series of norms for comparison. It is only by this method that the navigator has the information to determine that something is amiss. Perhaps there are storms between the LORSTAs and the vessel, perhaps a newly installed piece of shipboard equipment needs noise suppression, or the receivers ground has been impaired, etc. These phenomena or problems can only be detected by a systematic comparison of SNR values with historical norms which depend upon the make and model of receiver, installation technique, and vessel location.

#### Navigation Features

The above features of loran receivers would be, in themselves, more than satisfactory for navigational purposes. However, all modern lorans also incorporate a wide variety of navigational functions that, taken together, transform loran from simply an instrument to determine position (such as a hand bearing compass or a sextant) into a complete navigational system. Navigational information and functions of modern Loran-C receivers are next discussed.

#### The Loran-C receiver

knows the users position (in TD and/or latitude/longitude terms) at any instant in time. As well, the receiver has a very precise clock. Knowledge of position and time information enable the calculation of the users speed, course, and other relevant information for navigation.

#### Waypoints

As noted in earlier chapters, all Loran-C receivers in current production have the capability of entering and storing waypoints. These waypoints are simply sets of coordinates which describe a location of navigational interest. Waypoints could include a dockside location where the vessel is berthed, fixed and floating aids to navigation, channel centerlines, turnpoints, productive fishing areas, wrecks, shoals, etc.

Aviators would typically define different types of waypoints from those given above. Possible waypoints relevant to aviation uses of loran could include airports, locations of the initial approach fix, locations of radionavigation aids, airway intersections, locations of published holding fixes, turnpoints, and other relevant information. Note that aviation lorans equipped with a data base may have many of these locations preprogrammed in the loran. (A subscription service is available to update these locations.)

Waypoints can generally be entered into (and stored by) the loran either by visiting the area and pressing the appropriate control button on the set, or can be entered as coordinates (typically as TDs, latitude, longitude, or as distance and either true or magnetic bearing from another wapoint). The number of waypoints that can be stored in the receivers memory varies by make and model, but most receivers can store 100 or more waypoints. Waypoints are stored as a waypoint number and set of coordinates. Some receivers permit an alphanumeric waypoint designator (e.g., home, buoy 01, etc.) to be used.

In use, waypoints are either places to be visited (e.g., checkpoints along a route) or places to be avoided (e.g., shoals, rocks, or other obstructions to navigation). Often a navigator will lay out a sequence of waypoints, linked into an overall route for the voyage. The Loran-C receiver keeps track of the users progress from waypoint to waypoint. At all times, the user can determine the distance-to-go (DTG) and bearing (BRG) to the next waypoint in sequence, an angular course direction to the next waypoint, and the time-to-go (TTG) to reach the next waypoint. (These functions are discussed in more detail below.)

#### Cross Track Error

The cross track error, often abbreviated XTE on loran displays, is the perpendicular distance from the users present position to the intended track between waypoints. Nearly all modern Loran-C receivers can display the XTE optionally in nautical or statute miles. Cross-track error is illustrated in Figure IV

1, which shows the aircrafts intended track (the solid line) between two waypoints and the actual track, denoted by the dashed line. In this illustration, the aircraft has drifted to the right (south) of course. The bearing (BRG sometimes called course-to-steer [CTS]) would be the angle from the aircrafts present position, and the DTG, the distance (great circle) from the users present position to the next waypoint in sequence.

Knowledge of the XTE enables the user to alter the vessels or aircraft's course to compensate for the observed drift, effects of maneuvering to avoid traffic, and/or inattention at the helm. Additionally, many receivers display a course deviation indicator (CDI), often by an arrow, that indicates the appropriate angular correction to return to course. It is important to remember that the mere fact that the loran indicates the XTE does not imply that there is safe water or airspace between the vessel and the waypoint. It is the navigators responsibility to check the appropriate charts to determine if a course alteration can be made safely. If an autopilot is coupled to the loran receiver, the autopilot will maintain a correct course to the next waypoint.

To simplify navigation, many receivers enable an adjustable XTE alarm to be set, so as to warn the user when a pre-defined XTE tolerance is exceeded.

Figure IV

2 shows this graphically. As in the first illustration, the vessel is assumed to be in transit between two waypoints. The XTE alarm is an audible alarm that can be set to warn the mariner of any excursions outside of a lane of adjustable width between the waypoints. In Figure IV 2, for example, the XTE alarm would sound whenever the vessel strays into the shaded area.

An XTE alarm would typically be set for voyage legs where navigational hazards (e.g., shoals, rocks, heavily traveled shipping lanes, fish trap areas) lie to one side or the other of the intended track. The XTE alarm should be set so as to enable the vessel to return to course in ample time to avoid the navigational hazard. Therefore, the navigator should allow an adequate margin of safety to ensure safe passage. This safety margin should reflect, among other things, an allowance for the accuracy of the loran system, the reaction time of a distracted helmsman, and the speed and reaction capability of the vessel. Although vessels are generally thought of as being comparatively slow, these can still cover a surprising distance in a short span of time. A sport fisherman on plane at 30 knots, for example, will cover more than 1,500 ft in 30 seconds.

Incidentally, it is noted above that the distance to go (DTG) to the next waypoint is the great circle distance between the vessel (or aircraft's) present position and the waypoint. In circumstances where the vessel's intended course differs from this great circle, e.g., because the vessel is following a

meandering river, this DTG could be a significant understatement of the actual distance remaining. In turn, other navigationally relevant information based upon this quantity, such as the time to go, would also be in error. To minimize this error, the navigator should (within the memory limitations of the receiver) enter as many waypoints as necessary to represent the vessel's meandering course to destination. Failing this, the navigator should recognize that the distance to go may understate the actual miles over the route to be followed.

#### Other Alarms

The XTE (sometimes called off-course) alarm is only one of several adjustable alarms that can be set by the user to assist in navigation. Table IV 5 provides a list of several other alarms commonly incorporated into Loran-C receivers. These are next discussed. (Although these are described as audible alarms in the manufacturers literature, the sound of the alarm may not carry very far particularly in a noisy environment and some manufacturers provide for an external connection to a loud alarm.)<sup>10</sup>

Although alarms can be used to great advantage, these should be used judiciously. Many types of modern marine electronics are fitted with alarms those described below for the Loran, depth alarms on the sonar, intrusion alarms on radar sets, etc. The sound of numerous alarms going off simultaneously may actually complicate decision making in a hazardous situation. So, while it is nice to have the capability to set various alarms, these should be used with some discretion. Moreover, the navigator should be fully familiar with the sound or tone patterns of the various alarms lest valuable time be wasted in identifying which alarm has tripped.

#### Arrival Alarm

An arrival alarm can be programmed to sound whenever the vessel passes within a user-defined distance of the next waypoint in sequence. Figure IV 3 illustrates the arrival alarm. The arrival alarm will sound whenever the vessel penetrates the shaded area. The alarm can be turned off manually and, on some models, will automatically shut off whenever the vessel exits the shaded area in Figure IV-3. Arrival alarms are useful in circumstances of bad weather or otherwise restricted visibility to alert watchstanders to be particularly vigilant in searching for an entrance buoy, for example. The arrival alarm may also signal the helm to reduce speed to avoid overrunning or running into the waypoint (if a physical object such as a buoy or a light structure). Incidentally, many Loran systems use different tones or tone patterns for the different alarms. One manufacturer, for example, uses the Morse code A ( ) for the arrival alarm.

Generally speaking, an arrival alarm would be set only for those waypoints where some action is required by the operator or crew, such as a course or speed change. When traveling towards waypoints where no operator action is required, the alarm can be disabled. This practice is desirable because it reinforces the idea that, when an alarm sounds, some action must be taken by the operator. Alarms that sound routinely have a desensitizing effect (the cry wolf syndrome) which could mean that a genuinely significant alarm would be overlooked or that alarms will not be set in the first place.

Arrival alarms are particularly useful in cases where a waypoint must be reached exactly, and in circumstances (e.g., reduced visibility) with a high potential for distraction. As with the XTE alarm, the arrival alarm should be set at a sufficient distance to avoid overrunning the waypoint. Upon hearing the arrival alarm, the vessel operator would normally slow down and carefully monitor the DTG and BRG indications to steer to the waypoint. A prudent navigator should use all available means (e.g., depth sounder, radar) to help locate the waypoint. If the waypoint were an entrance buoy, for example, and visibility were impaired (e.g., by fog or darkness) the operator might wish to initiate a systematic search pattern to ensure that the buoy was located prior

to proceeding to the next waypoint.

#### Boundary (Border) Alarm

##### Figure IV

4 illustrates the border alarm. It may be thought of as the mirror image of the XTE alarm, warning the user that the vessel is about to penetrate a lane of defined width between two waypoints. This could be used to warn the mariner that the vessel has entered a traffic separation lane. As a second illustration, this feature might be used by a commercial fisherman to avoid illegal fishing areas of defined dimension. These illegal areas are separated from legal zones by an imaginary line between two points of latitude/longitude or TDs. Penalties for fishing within illegal areas can be very substantial, so many commercial fishing vessels find these alarms particularly useful.

#### Passing Alarm

##### Figure IV

5 illustrates the passing (sometimes termed the arrival off-course) alarm. As the name implies, this alarm warns the mariner that a waypoint has been passed (technically that the vessel has passed a line perpendicular to the intended track at the waypoint) without triggering the arrival alarm.

#### Anchor Watch

##### Figure IV

6 shows an anchor watch alarm, which might be thought of as the mirror image of the arrival alarm. The mariner defines a waypoint where the anchor is dropped, and an alarm circle sufficient to accommodate the swing circle of the vessel. (Directions for how to do this vary by make and model for some models the swing circle is preset, in other models it is adjustable.) The alarm will sound whenever the vessel penetrates the shaded area in other words whenever the anchor drags and the vessel drifts outside of a user-defined swing circle. The low power consumption of the loran ensures that the ship's battery won't be run down excessively if the generator is not running or not available and the loran is left on overnight so as to use the anchor watch.

Overall, an anchor watch is a desirable feature. But, it is important to have a realistic appreciation of the limitations of this feature. First, an anchor watch probably won't be of much help in a very crowded anchorage, where the swing circles of other vessels are just boat lengths away. The repeatable accuracy of a loran may not be sufficient for this purpose. Second, unless an external land alarm is fitted, the noise of the anchor alarm may not be sufficient to wake crew sleeping some distance from the loran receiver.

#### Course and Speed Information

As noted above, position and time data in the loran receiver enable the computation of course and speed estimates. In the case of loran, all course and speed estimates are referenced to motion over the ground, rather than motion relative to the water. Thus, for example, the course and speed estimates are really course-over-the-ground (COG) and speed-over-the-ground (SOG). COG and SOG information are particularly useful to the navigator, because these quantities reflect the combined effect of the vessel's motion through the water, and the current set and drift. When navigating to a destination, the user simply alters the heading of the vessel to maintain a zero XTE, or to maintain the COG equal to the intended track, and the vessel will arrive at the chosen waypoint. Navigators should remember that the vessel's heading (per standard compass) will generally differ from the COG, because of compass deviation and the correction or crab angle necessary to compensate for current (or winds aloft in the case of aircraft).

Reference to numerous owners manuals indicates that there is little-or-no uniformity in the nomenclature employed by various manufacturers to describe course and speed information. Moreover, the apparent definitions of these terms are generally at variance with accepted navigational nomenclature. For a summary of the traditional definitions of many course and speed terms, please refer to Appendix C. In what follows, the course and speed features of a sample of modern lorans are summarized.

All modern lorans have the capability to display COG and SOG or some reasonable facsimile of these quantities. (According to definitions used by some manufacturers, these are incorrectly termed course-made-good (CMG) and speed-made-good (SMG) respectively consult the owners manual for your set.) According to traditional definitions, the COG and SOG are instantaneous values. In the case of loran receivers, these quantities are in fact short-term average values, where the averaging period (e.g., from seconds to minutes) is adjustable by the user. Because of this time averaging, the values displayed by the receiver will lag the vessels actual direction and speed. e.g., the speed indication for a decelerating vessel will be overstated. Long averaging times (e.g., as many as 7 minutes for some models) will tend to be quite stable and accurate, provided the vessel does not alter speed. Short averaging times (e.g., 30 seconds) will track changes in the users speed more readily, but at the expense of stability.

Some receivers have the capability of determining the average course and speed (with respect to the ground) since the last waypoint i.e., arguably the true CMG and SMG values.

#### Velocity Made Good (VMG)

Illustrated in slightly exaggerated form in Figure IV

7, velocity made good (VMG) also called velocity along route (VAR) by at least one major manufacturer, and speed of advance (SOA) by another is a term very familiar to sailors. VMG represents the component of a vessels speed over the ground in the direction of the waypoint. In Figure IV

7, a sailing vessel is travelling from the waypoint to the west to the one to the east. The bearing of this second waypoint is 090 degrees from the first. However, in this example, because the wind is assumed to be coming from the east, the vessels actual track must consist of a series of tacks, with the result that the actual path over the ground is a series of zig-zags shown by the dotted line. Obviously, the distance along the dotted line between the two waypoints is larger than the great circle distance shown by the solid straight line. As a consequence, the overall VMG as measured along the solid line would be substantially smaller than the vessels SOG. In general, it can be shown that the relation between the average SOG and the VMG is equal to the cosine ( $\cos$ ) of the angle that the vessel's course makes with the intended track. If, for example, the angle between the actual track and the direct course between the two waypoints were 50 degrees, and the vessels SOG were 6 knots, the VMG would equal 6 knots times  $\cos(50)$ , or approximately 3.9 knots. The sailor has a practical optimization problem to solve. Generally speaking, a sailing vessel is faster off the wind than when sailing close to the wind. (The specific relation between the wind direction and the sailboat is termed a polar diagram, and differs from vessel to vessel.) But, sailing further off the wind increases the distance to be covered. The optimal course is one that maximizes the VMG. A Loran-C receiver that has the capability to display VMG could be very handy in determining the optimal course to steer. The mariner would make multiple minor adjustments on course, watching the loran closely (and allowing for averaging lags) finally setting on the course that maximizes the VMG.11

#### Velocity Towards Destination (VTD)

The velocity towards destination (VTD) is the average component of the vessels SOG along the direct course to the destination. The VTD will equal the SOG provided that the vessels COG is exactly equal to the bearing to the next waypoint. If not, the VTD is equal to the SOG multiplied by the cosine of the

angle between the COG and the bearing to the waypoint. Figure IV